

# aumüller

## Instructions for installation and commissioning



**EMB 7300 RADIO HSE SYSTEM**

01	<p>Abbreviations                  Warning and Safety symbols                  Target groups, Intended use                  Safety Instructions, Directives and Standards</p>	3 - 6
02	<p>Data Sheet for EMB 7300 Radio HSE System</p>	7 - 8
03	<p>Installation of the EMB 7300 Radio HSE System</p>	9 - 13
04	<p>Blink code</p>	14
05	<p>Storage and Disassembly                  Disposal                  Warranty and Customer Service                  Liability                  Certificate</p>	15 - 16
06		
07		
08		

## Abbreviations

Index of abbreviations	
The following abbreviations are used throughout these instructions. All units of measurement in the instructions are in mm, unless otherwise stated. General tolerances according to DIN ISO 2768-mK-E.	
aP	Surface mounted
WxHxD	Width x Height x Depth
CAN	CAN-BUS
CM	Control-Module
COM	Common connection
DIN	German Institute for Standardisation
DM	Drive-Module
EN	European Standard
IN	Input
LON	Local Operating Network
OUT	Output
PG	Price group
PM	Power-Module
PS	Power supply
RM6	Relay-Module
RWA	Smoke and heat exhaust
SM	Sensor-Module
uP	Flush mounted
WM	Weather-Module
WRG	Wind direction transmitter

Colour Codes according to IEC 60757					
BK	black	GY	grey	VT	violet
BN	brown	OG	orange	WH	white
BU	blue	PK	pink	YE	yellow
GN	green	RD	red		

Scale Units	
°C	Degree Celsius
A	Ampere
Ah	Ampere hour
dBm	Decibel milliwatts
kg	Kilogramme
m	Meter
min	Minute
mm	Millimetre
s	Seconds
V	Volt
VE (PU)	Packaging Unit
Vpp	Residual Ripple (Voltage peak-to-peak)
W	Watts
Ω / k Ω	Ohm / Kilo-Ohm

General Symbols	
AC	Alternating Current (50Hz / 60Hz)
DC	Direct Current
I	Electric Current
L	Length
ME	Module Space Unit (1 ME = 23 mm)
NC	Contact „closed“ (normally closed)
NO	Contact „opened“ (normally opened)
P	Electric Power
R	Electrical Resistance
U	Electric voltage
Um	Change-over switch

## Warning and Safety Symbols in these Instructions:

The symbols used in the instructions must be strictly observed and have the following meanings:

 **DANGER** Failure to comply with these warnings may result in permanent injury or death.

 **WARNING** Failure to comply with these warnings may result in permanent injury or death.

 **CAUTION** Failure to comply with these warnings may result in minor or moderate (reversible) injuries.

 **NOTE** Failure to comply with these notes may result in property damage.

 **Useful Note** for optimal installation.

 **Note regarding system configuration** setting options via the „Alpha“ configuration software.

 **Caution / Warning**  
Danger from electric current.

 **Attention / Warning**  
Risk of damage / destruction of Control Units, drives and / or windows.

## Target group

These instructions are intended for qualified personnel trained in electrical engineering and skilled operators of systems for natural smoke ventilation (NRA / RWA) (natural smoke exhaust / smoke and heat exhaust) and for natural ventilation via windows, who have knowledge of the operating modes and residual risks of the system.



This device is not intended for use by persons (including children) with limited physical, sensory or mental abilities or lack of experience and/or knowledge.

## Intended Use

### Area of Application / Scope of Application

This control device is intended for the supply and control of electrically operated windows in façade and roof areas. **The main task of this product**, in combination with the electromotive window, **is to remove hot smoke and fumes in case of a fire** in order to save human lives and protect material assets. **In addition**, the electromotive window ensures **the supply of fresh air for natural ventilation** of the building.

### Intended use according to the Declaration of Conformity

The control device is designed for fixed installation and electrical connection as part of a building.

In accordance with the attached Declaration of Conformity the control device, in combination with electromotive drives from **AUMÜLLER**, is approved for proper use on a power-operated window:

- Application for natural ventilation
  - installation height of the drive and the bottom side of the sash at least 2.5m above the floor, **or**
  - opening width at the HSK of the operating unit < 200 mm with a simultaneous speed of the HSK in closing direction of < 15 mm/s.
- Application as NRWG (natural smoke and heat exhaust ventilator) according to EN12101-2 without dual function for natural ventilation.

By connecting the window drives with a control device and commissioning them, the installer of the entire system becomes the manufacturer of the electric window!

### NOTE

The installer may be required to carry out a risk assessment of the entire system in accordance with the Machinery Directive 2006 / 42 / EC if the use or operation of the control unit or the connected window drives deviates from the intended use!

### NOTE

We recommend the exclusive use of **AUMÜLLER** system components, as their compatibility is carefully checked at the factory. **AUMÜLLER** does not assume any liability for the proper functioning of third-party components. For applications and connections other than those explicitly stated in these instructions, the express written consent of **AUMÜLLER** is required. The use of applications and components not expressly authorised by **AUMÜLLER** shall also be considered as not in accordance with the regulations even if their proper functioning can be proved when they are put into operation (e.g. by approval under building law).

## Safety Instructions



**WARNING**

It is important to follow these instructions for the safety of persons. These instructions must be kept in a safe place for the entire life of the product.

### Scope of application

The control device shall only be used according to its intended use. For additional applications, please contact the manufacturer or their authorised dealer.

### Installation

These instructions are intended for competent and safety-conscious electrical installers and/or qualified personnel with knowledge of the electrical and mechanical installation of drives and control systems.

### Mounting Material

The required mounting material must be modified to fit the applied load.

### Routing cables and electrical connection

The laying or installation of electrical cables and connections may only be carried out by approved specialist companies. Never operate the drives, controls, operating elements or sensors on operating voltages and connections contrary to the manufacturer's specifications.

**NOTE**

The planning and calculation of the line network is the responsibility of the building owner, their agents or the commissioned installer, and must be carried out in accordance with the statutory regulations.

All relevant regulations must be observed during installation, particularly:

- VDE 0100 Installation up high-voltage systems up to 1000 V
- VDE 0815 Installation cables and - / conductors
- Model Cable Systems Directive (MLAR).



The mains supply line of the Control Unit must be secured separately by the customer and provided with an all-pole disconnecting device. After opening the system housing, live parts are exposed. The system must be disconnected from the power supply and batteries before any work can be carried out on the Control Unit.

The cable types, cable lengths and cross-sections must be selected in accordance with the manufacturer's technical specifications. If necessary, the cable types must be approved by the responsible local authorities and power supply companies.



Cables must be laid in such a way that they are not sheared off, twisted or bent during operation. It is recommended to carry out an insulation measurement of the line network of the system and to document it.

Clamping points must be checked for tightness of screw connections and cable ends. The accessibility of junction boxes, terminal points and external drive controls for maintenance work must be ensured.

### Commissioning, operation and maintenance

After installation and after every change to the setup, all functions must be checked by a test run. After completion of the installation, the end user must be instructed in all important operating steps. If necessary, they must be informed of any remaining risks / dangers.

The end user must be informed about the intended use of the system and, if necessary, about the safety instructions.

**NOTE**

Put up warning signs!



Before working on the system, it must be completely disconnected from the power supply and emergency power supply (e.g. batteries) and secured against accidental reconnection. When working in the Control Unit, the workplace must be secured against unauthorised access. It must be ensured that unauthorised persons cannot open the Control Unit.

The installation instructions of system components (smoke detector, natural smoke and heat exhaust ventilators, drives, etc.) are part of the documentation of the overall system and, like the installation and operating instructions for the control unit, must be kept accessible to authorised specialists throughout the service life of the system.



**WARNING**

Carefully check all functions of the system before releasing it for operation.

### Software terms and conditions

The Control Unit is configured at the factory for its intended use (standard configuration). With the software specially developed for this Control Unit, the factory setting can be quickly and easily adapted to suit specific requirements. In addition, the system status can be saved, recalled and printed out.



Changeable standard configurations are highlighted in these instructions. The range of functions of the unlicensed version can be extended by license activation payment.



**EMB 7300 Radio HSE System: Radio HSE (Transmitter) and Radio Receiver**

**Application:** The **Radio HSE** is used to control the Emergency OPEN and Emergency CLOSE functions via a **Radio Receiver** in the detector line of the **EMB 7300 SHEV Control Unit**.

**Radio:** FM narrow bandwidth  
**Frequency:** 433.100 to 434.600

**Radio HSE Variants**

①	Radio HSE	Plastic red	(similar to RAL 3000)	<b>528340</b>
①	Radio HSE	Plastic yellow	(similar to RAL 1018)	<b>528341</b>
①	Radio HSE	Plastic grey	(similar to RAL 7035)	<b>528342</b>
①	Radio HSE	Plastic blue	(similar to RAL 5015)	<b>528343</b>
①	Radio HSE	Plastic orange	(similar to RAL 2011)	<b>528344</b>

**Inclusive: 3,6 V Lithium-Battery, > 2000mAh, Typ: 14500**

**Additional Equipment**

②	Radio Receiver	<b>528738</b>
③	Radio Antenna including holder	<b>528737</b>



For the use of **Radio HSE**, an **EMB 7300** firmware V0.1.9 or higher is required.

**Radio HSE and Radio Receiver**

The **Radio HSE** are connected to the **Radio Receiver** by radio (ISM band) and exchange a data packet (Ping) every 96 seconds to signal the "life status".

If a signal is generated on the **Radio HSE** (trigger button, reset button or fault) an encrypted data packet is immediately sent back to the **Radio Receiver** with a confirmation packet.


The radio system uses 6 frequencies for the **Radio HSE**. The total number of all **Radio HSE** must not exceed 10 detectors per system.

- Long service life of the battery-powered **Radio HSE**
- High security for all transmission channels
  - AES encrypted packets in the event of triggering
  - Hand-shake for radio and serial data
  - Distribution on 6 frequencies against jamming transmitters
- High range in buildings
  - VNA optimised **Radio HSE** antennas for horizontal and vertical radio alignment
  - 433MHz ISM narrow bandwidth with 1.2kbps

**Connection: Radio Receiver on EMB 7300**


Slot for radio module

**Plug-in direction:**  
Antenna connection towards main board



For commissioning the licensed version of the configuration software **EMB Compact** is absolutely necessary!

Assembly: HSE button (break-glass unit)



**NOTE**

Please attach **tear-off contact 1** to the housing / wall!  
 A fault is triggered if the **connection between the tear-off contact and the circuit board** is interrupted.  
 Duration approx. 90s.

Explanation	
2	power indication
3	fault indicator
4	Emergency OPEN incl. Emergency OPEN LED
5	reset button
6	restart button

**NOTE**


**Press the restart button 6**  
 A restart of the radio HSE is triggered when the actuation time is less than 500ms.  
 A longer press does not lead to a restart, which is indicated by the green LED flashing quickly.

## EMB 7300 Radio HSE System

If the network option Radio HSE is selected under System Properties, the following tab appears in the left-hand menu: „Radio HSE“.



The licensed version of the „EMB Kompakt“ software is required in order to change the network options and to programme and configure the radio HSE buttons.



After selecting the network option „Radio HSE“ and the desired frequency group (this is set on the system and the push-button), the change must be saved in the control panel. No push-buttons can be programmed before this.

### NOTE

## INSTALLING STEP 1:

### Select frequency group:

A predefined frequency group can be selected for the radio link of the **EMB 7300 Radio HSE** via the 4 selection fields under Frequency Group:

Frequency Groups (MHz)	
Group A	433.100, 433.700, 434.450, 433.300, 434.225, 433.500, 434.000
Group B	433.150, 433.750, 434.500, 433.350, 434.275, 433.550, 434.050
Group C	433.200, 433.800, 434.550, 433.400, 434.325, 433.600, 434.100
Group D	433.250, 433.850, 434.600, 433.450, 434.375, 433.650, 434.150

## INSTALLING STEP 2:

### Preparing the push-button:

- Press and release the restart button - this is bottom right (**green LED** flashes quickly).
- Then immediately press and hold the reset button.
- The **red LED** flashes.
- When the **red LED** stops flashing, release the reset key.
- The push-button is reset.
- Do not re-insert the circuit board holder into the housing yet.

## INSTALLING STEP 3:

### Set the frequency group on the HSE buttons:

- Press and release the restart button - this is bottom right (**green LED** flashes quickly).
- Hold down the reset button and the release key at the same time.
- All LEDs light up until the keys are released.
- The **red LED** now flashes for the group number (1 x for Group A, 2 x for Group B, etc.).  
Press the reset key to select the next group and the release key to accept the currently selected group.

**INSTALLING STEP 4:**

**Startup Phase on the HSE button:**

- Press the restart button at the bottom right (**green LED** flashes quickly for approx. 3s).
- The startup phase begins.


- This lasts approx. 20 seconds and is completed as soon as the **green** und **yellow LED** flash simultaneously.
- The button is now ready to be programmed.

**INSTALLING STEP 5:**



**Programming push-buttons in the system**

- When Installing Step 4 is completed, the push-buttons can be programmed on a Control Unit.
- Start the software and select the tab "Radio HSE". There is a „Plus“ button **+** under the selection of frequency groups.

- On all manual call points
  - that do not have an assigned address
  - are in the correct frequency group and
  - are within reach
 the „**Emergency OPEN LED**“ (**red LED** on the push button) now starts to flash.
- To complete the programming process, the „**Emergency OPEN**“ button in the HSE button must be pressed. After a few seconds the button is programmed and appears in the configurator.



- When the „Plus“ **+** button is pressed, the system switches to search mode and sends a "Search Signal" to all manual call points.
- The signal lasts for 3 minutes.



## Range checker function (RF analysis)

The range tester can only be used if the wireless HSE button has already been taught in (INSTALLING STEP 1 - 5).

**NOTE**

If the radio contact has been lost over a longer period of time, a restart is required in order to synchronize the radio HSE button again (press the restart button once).

**Functional description:**

The range checker measures the electrical field strength to the radio partner (EMB 7300) and signals the reception strength via the three built-in LED's.

The radio module of the EMB 7300 sends a beacon packet every 1.75s, which is analyzed by the range checker.

**Activation:**

1. Ensure battery supply and wait until the startup phase is complete.
2. The radio HSE button must be in the taught-in state.
3. Neustart-Taste unten rechts drücken und halten (ca. 3s) bis alle 3 LED's leuchten. Press and hold the restart button (approx. 3s) - at the bottom right - until all 3 LEDs light up.
4. When you release the restart button, the LEDs go out and one LED shows the electric field strength.


LED display for break-glass unit (HSE)

Indicator	Electric field strength	Meaning
A <input type="checkbox"/> OFF B <input type="checkbox"/> continuously ON S <input type="checkbox"/> OFF	$\geq -70$ dBm	Very good signal
A <input type="checkbox"/> OFF B <input type="checkbox"/> flash S <input type="checkbox"/> OFF	-80 to -71 dBm	Good signal
A <input type="checkbox"/> OFF B <input type="checkbox"/> OFF S <input type="checkbox"/> flash	-90 to 81 dBm	Sufficient signal
A <input type="checkbox"/> flash B <input type="checkbox"/> OFF S <input type="checkbox"/> OFF	-100 to -91 dBm	Bad signal
A <input type="checkbox"/> continuously ON B <input type="checkbox"/> OFF S <input type="checkbox"/> OFF	$< -100$ dBm	Very bad signal
A <input type="checkbox"/> continuously ON B <input type="checkbox"/> OFF S <input type="checkbox"/> flash	No signal	No signal Note the information of the radio contact!

**NOTE**


The range analysis is ended by briefly pressing the restart button .

It is recommended to change the battery after using the range analysis for regular operation.



## INSTALLING STEP 6: Edit Push-button

To edit a programmed push-button, simply left-click with the mouse on the desired push-button – the push-button’s editing menu opens:



### Normal Operation:

If all push-buttons have been properly programmed and the system is in normal operation (no fault is present), the **green LED** on the HSE push-button flashes, therefore signalling normal operation.

For energy-saving reasons, the LED on the radio HSE push-button flashes (on wired push-buttons, it is permanently lit).




All changes must be saved via the disk in the editing menu.



If you want to delete a key which has already been programmed, you can use the „Trash“ icon  in the software.



The respective indicators can be displayed with a delay of up to 30 seconds depending on the situation.



### Adjustable functions

<b>Name</b>	Here you can assign a name for each push button as free text.
<b>Address</b>	Hardware-bound – nothing can be changed here.
<b>Drive Lines</b>	Here you can set which drive lines (1 or 2 depending on the Control Unit variant) the HSE button should trigger.
<b>Status</b>	Info field, here the push-button reports its status (e.g. missing, if it is no longer recognised).
<b>Colour selection push button</b>	Here you can select the colour of the button for better orientation.

## Resetting a Button

To delete the addressing of a push-button (e.g. for programming to another installation), the following steps are necessary.

- Press the restart button at the bottom right (**green LED** flashes quickly for approx. 3s).
- Then immediately press and hold the reset button.
- **Red LED** flashes.
- When the **LED** stops flashing, release the push-button.



### Battery Change

The battery of the manual call point must be changed at least every 2 years (in standard operation).


In case of frequent malfunctions / tripping, an annual change may also be necessary. The exact battery status can be monitored via the central software.

### Additional Displays


<b>LED's</b>	Show the current status which the respective key reports back to.
<b>Battery</b>	Indicates the current battery charge level.
<b>Reception</b>	Displays the current signal strength of the button.
<b>Blue Points</b>	Shows which motor lines (1 or 2 or both) the button currently triggers.

**INSTALLING STEP 7:****Antenna**


- Use the screw **6** to put the lock washer **5**, the antenna head **4** and the antenna holder **3** together. Also make sure that the antenna head **4** is installed in the correct position.
- Insert the nut **1** in the cover **2**.
- Mount the cover **2** and nut **1** with the screw **6** on the antenna holder **3**.



- Mount the antenna **8** on the remaining threaded end of the screw **6**.



- Put the cap **7** on the antenna head **4**.



## Blink codes

### Meaning of the Displays (overview)



Basically, the green indicator „B” signals that the Control Unit works properly. A yellow indicator „S” lighting up signals a fault to be eliminated immediately.

Since the type of fault signal into the break-glass units may differ from the fault indicator „S” in the Control Unit, always pay regard to the indicators in the Control Unit for exact troubleshooting.

Explanation	
<b>B</b>	<b>GN</b> = green = Operation
<b>S</b>	<b>YE</b> = yellow = Fault
<b>A</b>	<b>RD</b> = red = Alarm (Emergency-OPEN)

### LED display for break-glass unit (HSE)

Indicator	State	State
<b>A</b> OFF	<b>B</b> OFF	HSE button is waiting for a sync packet. If no signal is received on the selected frequency, the frequency in the frequency group is switched first.
<b>S</b> ON		
<b>A</b> OFF	<b>B</b> OFF	
<b>S</b> flashes (1s cycle)		If no packet is received on all 6 frequencies, the HSE button goes into sleep mode for 4 minutes. Reactivation by Emergency-OPEN button.
<b>A</b> OFF	<b>B</b> continuance	startup phase
<b>S</b> flash		
<b>A</b> OFF	<b>B</b> flash	
<b>S</b> OFF		successful synchronization
<b>A</b> flash	<b>B</b> OFF	reset process
<b>S</b> OFF		
<b>A</b> to shine	<b>B</b> to shine	
<b>S</b> flash		start phase frequency group
<b>A</b> OFF	<b>B</b> flash	frequency group menu: group A - 1x red group B - 2x red
<b>S</b> OFF		
<b>A</b> OFF	<b>B</b> ON	
<b>S</b> OFF		operation
<b>A</b> OFF	<b>B</b> OFF	fault
<b>S</b> ON		
<b>A</b> ON	<b>B</b> OFF	
<b>S</b> OFF		alarm

## Storage and Dismantling

The Control Unit should only be stored in places protected from moisture, heavy contamination and high temperatures (not above 30 °C). Do not remove the packaging until the control unit is ready to be installed. Disconnect the batteries and store them separately if the control unit has already been used.

**When storing rechargeable batteries it is essential to observe the following:**



Keep the storage time of the lead acid batteries as short as possible, as the batteries discharge over time. The batteries must be recharged after seven months of storage at the latest. For recharging, either use a suitable charger or connect the batteries to an EMB Control Unit and supply it with mains voltage. In both cases the charging time is at least **8 hours** (depending on discharge).

If the Control Unit is to be permanently decommissioned, the legal regulations for destruction, recycling and disposal must be adhered to. The control unit contains plastic, metal and electrical components as well as batteries. Replaced batteries contain highly toxic pollutants and must therefore only be disposed of at the collection points stipulated by law.



Before removing the Control Unit, it must be disconnected from the mains at all poles!

## Disposal

Do not throw electrical appliances in the household waste! According to the European Directive 2012 / 19 / EU on Waste Electrical and Electronic Equipment (WEEE) and its implementation in national law, electrical equipment that is no longer usable must be collected separately and sent for environmentally friendly recycling.



## Warranty and Customer Service

In principle, the following applies:

„General Terms of Delivery for Products and Services of the Electrical Industry (ZVEI)“.

„Terms of Delivery for the software used“.

The warranty complies with the legal requirements and applies to the country in which the product was purchased.

The warranty extends to material and manufacturing defects that occur under normal use.

The warranty period for material delivery is twelve month.

Warranty and liability claims for personal injury and damage to property are excluded if they are attributable to one or more of the following cause:

- Improper use of the product.
- Improper installation, commissioning, operation, maintenance or repair of the product.
- Operating the product with defective, incorrectly installed or non-functional safety and protective devices .
- Failure to observe the instructions and installation requirements in these instructions.
- Unauthorized structural changes to the product or accessories.
- Catastrophes caused by foreign bodies and Acts of God.
- Wear and tear.

The contact person for possible warranties or for spare parts or accessories is the branch office responsible for you or your responsible clerk at:


**AUMÜLLER AUMATIC GMBH.**

The contact details are available on our website


([www.aumueller-gmbh.de](http://www.aumueller-gmbh.de))

## Liability

Product changes and product adjustments can be made without prior notice. Illustrations are not binding. Despite the greatest possible care, no liability can be accepted for the content of these instructions.







## Certificate and Declaration of Conformity

We declare with sole responsibility that the product complies with the following directives:

- CE**
- 2014/30/EU Electromagnetic Compatibility Directive
  - 2014/35/EU Low-voltage Regulation

Technical documents and explanations at company:

**AUMÜLLER AUMATIC GmbH**  
 Gemeindewald 11  
 D-86672 Thierhaupten

Ramona Meinzer  
 Managing Director (Chairwoman)

### NOTE:

The proof of the application of a quality management system is for company:

**AUMÜLLER AUMATIC GmbH**  
 according to the certification basis **DIN EN 9001** as well as the installation and conformity declaration are available via the QR code below or directly on our website:  
 ([www.aumueller-gmbh.de](http://www.aumueller-gmbh.de))



### This is a Translation of the Original German Instructions for Installation and Commissioning

**Important Note:**

We are aware of our responsibility to act with the greatest possible care in the presentation of products that save lives and preserve value.

Although we make every effort to keep all data and information as up-to-date as possible, we cannot guarantee that it is free of errors.

The information and data contained in this document are subject to change without notice.

The distribution and reproduction of this document, as well as the use and communication of its contents are not permitted unless specifically authorised.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the granting of a patent or registration of a utility model.

For offers, deliveries and services the terms of business and delivery of **AUMÜLLER AUTOMATIC GmbH** shall exclusively apply.

With publication of these instructions all previous editions become invalid.

AUMÜLLER AUMATIC GMBH  
Gemeindewald 11  
86672 Thierhaupten

Tel. +49 8271 8185-0  
Fax +49 8271 8185-250  
info@aumueller-gmbh.de

**[www.aumueller-gmbh.de](http://www.aumueller-gmbh.de)**

90000029201\_V0.6\_KW12.2024