

RWA1000 套件装于内开上悬窗、下悬窗或平开窗时的安装尺寸																	
套件	窗框支架	开窗器行程	窗户关闭时			安装尺寸 “X”	FAH (NSK) (侧边)	开启角度	开启宽度	窗户开启时			窗扇宽度 (最大)		窗框上的安装空间		FAB (HSK)
			开窗器与竖框 夹角	开窗方向的 分解力						开启角度	开窗方向的 分解力		PL6	PL10	NSK	HSK	
				PL6	PL10						PL6	PL10					
			[DEG]	[N]	[N]	[mm]	[mm]	[DEG]	[mm]	[DEG]	[N]	[N]	[Kg]	[Kg]	[mm]	[mm]	
RWA 1000 (*1)	K15	100	19	195	326	200	600	25	260	48	447	745	30	50	40	40	取决于所用的电锁 (*2)
							800	17	236	46	430	717	43	72			
						250	750	22	286	47	442	736	29	49			
							1000	15	261	45	426	710	43	71			
						300	900	20	313	47	437	729	29	49			
							1200	13	272	45	422	703	42	70			
		150	16	165	276	225	675	34	395	57	503	838	34	56	40	40	
							900	23	359	52	474	790	47	79			
						275	825	30	427	55	490	817	33	54			
							1100	20	382	51	467	778	47	78			
						325	975	28	472	54	487	811	32	54			
							1300	18	407	50	462	769	46	77			
		200	15	155	259	250	750	42	538	64	541	902	36	60	40	40	
							1000	27	467	57	503	839	50	84			
						300	900	38	586	62	531	885	35	59			
							1200	24	499	56	497	829	50	83			
						350	1050	35	631	61	523	872	35	58			
							1400	22	534	55	491	818	49	82			
		250	13	135	225	275	825	50	697	71	567	945	38	63	40	40	
							1100	31	588	62	528	880	53	88			
						325	975	45	746	68	557	928	37	62			
							1300	28	629	60	519	865	52	87			
						375	1125	41	788	66	549	915	37	61			
							1500	25	649	59	513	854	51	85			
300	12	125	208	300	900	56	845	77	584	973	39	65	40	40			
					1200	35	722	65	544	907	54	91					
				350	1050	51	904	74	576	959	38	64					
					1400	31	748	63	536	893	54	89					
				400	1200	46	938	71	569	948	38	63					
					1600	28	774	62	529	882	53	88					
450	1350	43	990	69	561	935	37	62									
	1800	26	810	61	523	872	52	87									
	1500	40	1026	68	555	925	37	62									
	2000	24	832	60	519	864	52	86									

(\*1) 对于双开窗器套件 RWA1000 TE, 开窗器的力和开窗器所能推开的最大窗户宽度相应增高

(\*2) FV1 - 1x = 450 mm  
FV1 - 2x = 1200 或 2000 mm  
FV1 - 3x = 2000 mm